

**OUTSIDE**

|                                 |                                |
|---------------------------------|--------------------------------|
| Check fuel                      | Call Signature<br>781-274-0010 |
| Remove canopy cover & tail lock |                                |
| Store in baggage area           |                                |

**COCKPIT**

|                     |                        |
|---------------------|------------------------|
| <b>Magnetos</b>     | <b>Keys on console</b> |
| <b>Mixture</b>      | <b>CUTOFF</b>          |
| <b>Throttle</b>     | <b>IDLE</b>            |
| Hobbs & Tach        | Record                 |
| Documents           | AR(R)OW                |
| Flight controls     | Released               |
| Parking brake       | As-Required            |
| Circuit breakers    | All In                 |
| Electrical switches | All Off                |
| Strobes             | On                     |
| Master switch       | On                     |
| Annunciator         | Test                   |
| Exterior lights     | On / Night             |
| Pitot heat          | On / IMC               |

**LIGHT CHECK**

|            |                    |
|------------|--------------------|
| Right wing | Strobe / Nav Light |
| Nose       | Landing Light      |
| Left wing  | Stall Horn         |
|            | Strobe / Nav Light |
|            | Pitot Heat         |
| Tail       | Strobe             |

**COCKPIT**

|                       |            |
|-----------------------|------------|
| Pitot heat            | Off        |
| Exterior lights       | Off        |
| Master switch         | <b>Off</b> |
| Pitot & static drains | Drain      |
| Flight controls       | Check      |
| Fire extinguisher     | Check      |
| Flaps                 | Extended   |

**WALK AROUND**

| <b>Right Wing</b>  | <b>General condition</b> |
|--------------------|--------------------------|
| Flap               | Check                    |
| Aileron            | Check                    |
| Wingtip            | Check                    |
| Tie down           | Remove                   |
| Stall strip        | Check                    |
| Fuel tank vent     | Check                    |
| Fuel sump #1       | Check / FOD              |
|                    | Check / Water            |
|                    | Check / Leaks            |
| Fuel tank quantity | Check                    |
| Fuel cap vent      | Check                    |
| Main gear & brake  | Check                    |
| Fresh air inlet    | Check                    |

| <b>Nose</b>       | <b>General condition</b> |
|-------------------|--------------------------|
| Engine cowling R  | Open                     |
| General condition | Check                    |
| Oil               | No Leaks<br>5.5L – 6.0L  |
| Engine cowling R  | Latched                  |
| Prop & Spinner    | Check                    |
| Alternator belt   | Check                    |
| Air inlets        | Check                    |
| Exhaust pipes     | Secure                   |
| Nose gear         | Check                    |
| Wheel chock       | Removed                  |
| Engine cowling L  | Open                     |
| General condition | Check                    |
| Engine cowling L  | Latched                  |
| Fuel sump #2      | Check / FOD              |
|                   | Check / Water            |
|                   | Check / Leaks            |

**WALK AROUND CONT.**

|                    |                          |
|--------------------|--------------------------|
| <b>Left Wing</b>   | <b>General condition</b> |
| Fresh air inlet    | Check                    |
| Main gear & brake  | Check                    |
| Fuel tank vent     | Check                    |
| Fuel sump #3       | Check / FOD              |
|                    | Check / Water            |
|                    | Check / Leaks            |
| Fuel tank quantity | Check                    |
| Fuel cap vent      | Check                    |
| Stall strap        | Check                    |
| Tie down           | Remove                   |
| Wingtip            | Check                    |
| Aileron            | Check                    |
| Flap               | Check                    |

|                      |                          |
|----------------------|--------------------------|
| <b>Left Fuselage</b> | <b>General condition</b> |
| Antennas             | Check                    |
| Fresh air inlet      | Check                    |

|                  |                          |
|------------------|--------------------------|
| <b>Empennage</b> | <b>General condition</b> |
| Stabilator       | Check / Clear            |
| Trim tab & nut   | Check / Clear            |
| Rudder           | Check / Clear            |

|                       |                          |
|-----------------------|--------------------------|
| <b>Right Fuselage</b> | <b>General condition</b> |
| Antennas              | Check                    |
| Baggage area          | Secure                   |
| Baggage door          | Latched                  |

**COCKPIT**

|                    |            |
|--------------------|------------|
| Flaps              | Retract    |
| Seatbelts          | Check      |
| Passenger briefing | Complete   |
| Fuel selector      | Fullest    |
| Circuit breakers   | All In     |
| Brakes             | Set / Hold |

**FREQUENCIES**

|               |        |
|---------------|--------|
| <b>KBED</b>   | 124.6  |
| Ground        | 121.7  |
| Tower         | 118.5  |
| BOS App       | 124.4  |
| <b>KOWD</b>   | 119.95 |
| Ground        | 121.8  |
| Tower         | 126.0  |
| BOS App.      | 124.1  |
| <b>KASH</b>   | 125.1  |
| Ground        | 121.8  |
| Tower         | 133.2  |
| BOS App.      | 124.9  |
| Guard         | 121.5  |
| Practice Area | 123.5  |